

INSTALLATION INSTRUCTION  
**2.5" Low Voltage - Electronic Non-IC Remodel**  
HR-801

WAC LIGHTING  
Responsible Lighting®

**SAFETY INSTRUCTION**

IMPORTANT: NEVER attempt any work without shutting off the electricity.

- Read all instructions before installing.
- For installation by a qualified electrician.
- System is intended for installation in accordance with National Electric Code, and local regulations. Consult with local inspector to assure compliance.
- To reduce the risk of fire, electrical shock and injuries to persons, turn off power at main switch before installing or modifying the system.
- Retain instructions for future maintenance reference.

**OVERVIEW**

Housing is non-insulation contact, remodeling type, and 50 watts maximum. Trim and housing combination will determine maximum trim wattage. Housing requires a trim from the HR-800 series, and lamp to be complete (ordered separately). If dimming, will generally work with standard electronic low voltage dimmers.

**CUT OUT:**

1. Use the template (supplied) to make a 3" cut out hole in the existing ceiling.
2. Pull ceiling wire through the hole.

**WIRING:**



1. Junction box is suitable for chain wiring of multiple fixtures and is supplied with a spring latch door, and two trade size knockouts for BX or Romex® connectors.
2. Remove junction box door and connect fixture wires to building wires: Green ground wire to bare copper or green building wire, white fixture wire to white neutral wire, black fixture wire to (hot) black wire.
3. Secure with wire nuts (supplied).
4. Replace junction box door.

**MOUNTING:**


1. Pivot the J box up through the hole, followed by the can.
2. Hold the rim snug to the ceiling surface.
3. From inside the housing push and pivot the housing clips so they make contact with the top of the ceiling  
Note: 3/4 inch maximum ceiling thickness.

**FINISHING:**

1. Socket wire is sufficient in length to be attached to the pins of the lamp before it is inserted.
2. Push the trim assembly up until the trim ring is flush to the ceiling.



Push springs outward from inside the can.



HR-8000-SOCKET

WAC Lighting  
www.waclighting.com  
Phone (800) 526.2588 • Fax (800) 526.2585

Headquarters/Eastern Distribution Center  
44 Harbor Park Drive • Port Washington, NY 11050  
Phone (516) 515.5000 • Fax (516) 515.5050

Western Distribution Center  
1750 Archibald Ave • Ontario, CA 91761  
Phone (800) 526.2588 • Fax (800) 526.2585